

Vitrek 95x LabVIEW VI Finder

Here are the 95x commands supported and where they can be found in Vitrek 95x LabVIEW folders:

Commands grouped by category:

Configuration and Setting commands		
Command	VI name	Folder
DIO	DIO.vi	Public / Configure / Settings
BEEP	BEEP.vi	Public / Configure / Settings
CONSTSENSE	CONSTSENSE.vi	Public / Configure / Settings
DATE	DATE.vi	Public / Configure / Settings
FAILARC	FAILARC.vi	Public / Configure / Settings
FASTBRKDN	FASTBRKDN.vi	Public / Configure / Settings
FASTRERUN	FASTRERUN.vi	Public / Configure / Settings
HVSAFETY	HVSAFETY.vi	Public / Configure / Settings
MAXDISCHARGE	MAXDISCHARGE.vi	Public / Configure / Settings
MINLOAD	MINLOAD.vi	Public / Configure / Settings
SWITCHES	SWITCHES.vi	Public / Configure / Settings
TIME	TIME.vi	Public / Configure / Settings
VLIMIT	VLIMIT.vi	Public / Configure / Settings
Commands for creating and editing test steps and test sequences		
Command	VI name	Folder
ADD, ACEZ	ConfigureACEZ.vi	Public / Configure
ADD, ACW	ConfigureACW.vi	Public / Configure
ADD, DCEZ	ConfigureDCEZ.vi	Public / Configure
ADD, DCW	ConfigureDCW.vi	Public / Configure
ADD, GBEZ	ConfigureGBEZ.vi	Public / Configure
ADD, GB	ConfigureGB.vi	Public / Configure
ADD, LowOhm	ConfigureLowOhm.vi	Public / Configure
ADD, ACCAP	ConfigureACCAP.vi	Public / Configure
ADD, DCIR	ConfigureDCIR.vi	Public / Configure
ADD, ACI	ConfigureACI.vi	Public / Configure
ADD, DCI	ConfigureDCI.vi	Public / Configure
ADD, PULSE	ConfigurePULSE.vi	Public / Configure
ADD, BRKDN	ConfigureBRKDN.vi	Public / Configure
ADD, PAUSE	ConfigurePAUSE.vi	Public / Configure
ADD, HOLD	ConfigureHOLD.vi	Public / Configure

ADD, SWITCH	ConfigureSWITCH.vi	Public / Configure
NAME	NAME.vi	Public / Configure
NOSEQ	NOSEQ.vi	Public / Configure
RCL	RCL.vi	Public / Configure
SAVE	SAVE.vi	Public / Configure
Commands for Test Result Query		
Command	VI name	Folder
MEASRSLT?	MEASRSLT-Query.vi	Public / Data
STEPRSLT?	STEPRSLT-Query.vi	Public / Data
RSLT?	RSLT-Query.vi	Public / Data
STAT?	STAT-Query.vi	Public / Data
Misc. Commands		
Command	VI name	Folder
ERR?	ERR-Query.vi	Public / Utility
*RST	RST-Default.vi	Public / Utility
*IDN?	IDN-Query.vi	Public / Utility
Other Commands		
Command	VI name	Folder
ABORT	ABORT.vi	Public / Action-Status
LOCAL	LOCAL.vi	Public / Action-Status
LOCKOUT	LOCKOUT.vi	Public / Action-Status
*RST	RST.vi	Public / Action-Status
RUN	RUN.vi	Public / Action-Status
SEQ?	SEQ-Query.vi	Public / Action-Status
READY	READY.vi	Public / Action-Status
STEP?	STEPS-Query.vi	Public / Action-Status
CONT	CONT.vi	Public / Action-Status

VI for creating Test Steps and Test Sequence.

VI name	Sequence of VIs found inside	Folder
AddACWSEQ.vi	(NOSEQ.vi – ConfigureACW.vi – NAMESEQ.vi – SAVESEQ.vi)	Public / Application
AddACEZSEQ.vi	(NOSEQ.vi – ConfigureACEZ.vi – NAMESEQ.vi – SAVESEQ.vi)	Public / Application
AddDCWSEQ.vi	(NOSEQ.vi – ConfigureDCW.vi – NAMESEQ.vi – SAVESEQ.vi)	Public / Application
AddDCEZSEQ.vi	(NOSEQ.vi – ConfigureDCEZ.vi – NAMESEQ.vi – SAVESEQ.vi)	Public / Application
AddGBSEQ.vi	(NOSEQ.vi – ConfigureGB.vi – NAMESEQ.vi – SAVESEQ.vi)	Public / Application
AddGBEZSEQ.vi	(NOSEQ.vi – ConfigureGBEZ.vi – NAMESEQ.vi – SAVESEQ.vi)	Public / Application
AddACAPSEQ.vi	(NOSEQ.vi – ConfigureACCAP.vi – NAMESEQ.vi – SAVESEQ.vi)	Public / Application
AddDCIRSEQ.vi	(NOSEQ.vi – ConfigureDCIR.vi – NAMESEQ.vi – SAVESEQ.vi)	Public / Application
AddACISEQ.vi	(NOSEQ.vi – ConfigureACI.vi – NAMESEQ.vi – SAVESEQ.vi)	Public / Application
AddDCISEQ.vi	(NOSEQ.vi – ConfigureDCI.vi – NAMESEQ.vi – SAVESEQ.vi)	Public / Application
AddPULSESEQ.vi	(NOSEQ.vi – ConfigurePULSE.vi – NAMESEQ.vi – SAVESEQ.vi)	Public / Application
AddBRKDNSEQ.vi	(NOSEQ.vi – ConfigureBRKDN.vi – NAMESEQ.vi – SAVESEQ.vi)	Public / Application
AddPAUSESEQ.vi	(NOSEQ.vi – ConfigurePAUSE.vi – NAMESEQ.vi – SAVESEQ.vi)	Public / Application
AddHOLDSEQ.vi	(NOSEQ.vi – ConfigureHOLD.vi – NAMESEQ.vi – SAVESEQ.vi)	Public / Application
AddLowOhmSEQ.vi	(NOSEQ.vi – ConfigureLowOhm.vi – NAMESEQ.vi – SAVESEQ.vi)	Public / Application
RunSEQ.vi	(RCLSEQ.vi – SEQ status.vi -- STEPFLAG.vi -- STEPRSLT.vi)	Public / Application

Commands in A-Z order:

Command	VI name	Folder
ABORT	ABORT.vi	Public / Action-Status
ADD, ACI	ConfigureACI.vi	Public / Configure
ADD, ACCAP	ConfigureACCAP.vi	Public / Configure
ADD, ACEZ	ConfigureACEZ.vi	Public / Configure
ADD, ACW	ConfigureACW.vi	Public / Configure
ADD, BRKDN	ConfigureBRKDN.vi	Public / Configure
ADD, DCEZ	ConfigureDCEZ.vi	Public / Configure
ADD, DCI	ConfigureDCI.vi	Public / Configure
ADD, DCIR	ConfigureDCIR.vi	Public / Configure
ADD, DCW	ConfigureDCW.vi	Public / Configure
ADD, GB	ConfigureGB.vi	Public / Configure
ADD, GBEZ	ConfigureGBEZ.vi	Public / Configure
ADD, HOLD	ConfigureHOLD.vi	Public / Configure
ADD, LowOhm	ConfigureLowOhm.vi	Public / Configure
ADD, PAUSE	ConfigurePAUSE.vi	Public / Configure
ADD, PULSE	ConfigurePULSE.vi	Public / Configure
ADD, SWITCH	ConfigureSWITCH.vi	Public / Configure
BEEP	BEEP.vi	Public / Configure / Settings
CONSTSENSE	CONSTSENSE.vi	Public / Configure / Settings
CONT	CONT.vi	Public / Action-Status
DATE	DATE.vi	Public / Configure / Settings
DIO	DIO.vi	Public / Configure / Settings
ERR?	ERR-Query.vi	Public / Utility
FAILARC	FAILARC.vi	Public / Configure / Settings
FASTBRKDN	FASTBRKDN.vi	Public / Configure / Settings
FASTRERUN	FASTRERUN.vi	Public / Configure / Settings
HVSAFETY	HVSAFETY.vi	Public / Configure / Settings
*IDN?	IDN-Query.vi	Public / Utility
LOCAL	LOCAL.vi	Public / Action-Status
LOCKOUT	LOCKOUT.vi	Public / Action-Status
NAME	NAME.vi	Public / Configure
NOSEQ	NOSEQ.vi	Public / Configure
MAXDISCHARGE	MAXDISCHARGE.vi	Public / Configure / Settings
MEASRSLT?	MEASRSLT-Status.vi	Public / Data
MINLOAD	MINLOAD.vi	Public / Configure / Settings
RCL	RCL.vi	Public / Configure
READY	READY.vi	Public / Action-Status
RSLT?	RSLT-Query.vi	Public / Data
*RST	RST-Default.vi	Public / Utility
RUN	RUN.vi	Public / Action-Status

SAVE	SAVE.vi	Public / Configure
SEQ?	SEQ-Query.vi	Public / Action-Status
STAT?	STAT-Query.vi	Public / Data
STEP?	STEPS-Query.vi	Public / Action-Status
STEPRSLT?	STEPRSLT-Status.vi	Public / Data
SWITCHES	SWITCHES.vi	Public / Configure / Settings
TIME	TIME.vi	Public / Configure / Settings
VLIMIT	VLIMIT.vi	Public / Configure / Settings